





HOME TEAM RUNS THE SCORE CLOCK, UNLESS VISITORS OFFER A WILLING SCOREKEEPER.

PLEASE KEEP TRACK OF RUNS & INNINGS, ALL OTHER STATS ARE OPTIONAL.

TO CLEAR THE SCOREBOARD, UNPLUG THE POWER



BUTTON	BUTTON TITLE/ COLOUR	FUNCTION
	HOME SCORE +1 (BLUE)	PRESS ONCE TO ADD 1 RUN TO THE HOME TEAM. (SEE #1 ABOVE)
	GUEST SCORE +1 (YELLOW)	PRESS ONCE TO ADD 1 RUN TO THE GUEST TEAM. (SEE #2 ABOVE)
	INNING (GREEN)	PRESS ONCE TO ADVANCE TO NEXT HALF INNING OR NEW INNING. (SEE #3 ABOVE)